



## **Ansys + Formula Student Team of TU Berlin**


“Ansys was instrumental in our design process. Beyond providing engineering expertise, they granted us access to their powerful simulation clusters. With full access to Ansys and their Learning Hub, FaSTTUBe was able to conduct in-depth analyses of CFRP layups and mechanical investigations. This significantly reduced both costly testing time and vehicle mass, which is especially critical for components like wheels that contribute to rotational and unsprung mass.”

— **Jonas Pagel**

Vehicle Dynamics Engineer / Formula Student Team of TU Berlin

## / Developing a Hybrid CFRP Wheel for Formula Student Using Additive Manufacturing Processes


A reduction in the weight of a racing vehicle can lead to significant improvements in its performance abilities, resulting in enhanced acceleration, handling and responsiveness. Particularly, a reduction in the unsprung corner weight, which is largely comprised of the tires and wheels, can improve the car's ability to maintain contact between the tires and the road surface. To reduce the unsprung corner weight, decreasing the weight of the wheel itself through a concept of a new lightweight part using composite materials with additive manufactured components was a challenge to address.



Draped surface ply

Outer Layer  
Ansys  
2024 R1

© Structural Optimization  
Topology Density  
Type: Topology Density  
Iteration Number: 40  
05.05.2024 13:12



Surface model generated by level-set topology optimization

## / Challenges


The main challenge was to develop a component combining topology optimization as well as carbon-fiber-reinforced plastic (CFRP) layups while maintaining structural integrity and saving weight. As the developed part is supposed to be manufactured, detailed analysis and layup plots of the CFRP wheel have to be generated. To determine the ideal composite, material testing according to respective standards was performed. The bead of the wheel was optimized using parametrized CFRP layup sequences defining thickness and width.

## / Technology Used

- Ansys Mechanical™ software
- Ansys Discovery™ software
- Ansys Composite PrePost (ACP) capability

## / Engineering Solutions

The generation of draped-ply simulation and parametrized layup optimization was a handy tool in determining and justifying the best layup decisions. Parametrizing the ply width and angle of fibers greatly helped optimize the CFRP wheel in ACP.



3D printed titanium rim stars, including support structures

For the topology-optimized rim star, comparing materials with different properties helped the team decide on the best solution in terms of weight and stiffness. The rim star compared different materials through topology optimization, showing that a part made from titanium had the largest potential. The optimal combination to minimize compliance while maintaining favorable suspension dynamics was then chosen and manufactured for the FaSTTUBe race cars.

## / Benefits


Through the intuitive user interface and tools of ACP and Mechanical software, the team was able to quickly identify points of action. They could see areas that were of high and low interest in the optimization. As a result, the optimized wheel was considerably lighter than the established benchmarks, reducing the rim weight by 25% and the overall vehicle weight by 1.6 kg while maintaining structural integrity. Future work will validate the developed part on track.




Inflated tires on optimized CFRP rim

## / Company Description

FaSTTUBe, the Formula Student Team of Technische Universität Berlin, competes in various competitions across Europe, including FSN, FSCZ, FSG, and FSA in 2024. Additionally, they will be the first European team to attend FS China since 2016. Currently ranked 11th in the world, they hold the title of the highest-ranked Emrax-driven Formula Student team globally. This year's car concept focuses on maximizing the potential of the design, incorporating significant weight savings, particularly in the wheel assembly.



Rendering the CFRP rim with final rim star



FaSTTUBe team

**ANSYS, Inc.**  
Southpointe  
2600 Ansys Drive  
Canonsburg, PA 15317  
U.S.A.  
724-746-3304  
[ansysinfo@ansys.com](mailto:ansysinfo@ansys.com)

When visionary companies need to know how their world-changing ideas will perform, they close the gap between design and reality with Ansys simulation. For more than 50 years, Ansys software has enabled innovators across industries to push boundaries by using the predictive power of simulation. From sustainable transportation to advanced semiconductors, from satellite systems to life-saving medical devices, the next great leaps in human advancement will be powered by Ansys.

*Ansys and any and all ANSYS, Inc. brand, product, service and feature names, logos and slogans are registered trademarks or trademarks of ANSYS, Inc. or its subsidiaries in the United States or other countries. All other brand, product, service and feature names or trademarks are the property of their respective owners.*

Visit [www.ansys.com](http://www.ansys.com) for more information.

©2024 ANSYS, Inc. All rights reserved.